

Wiring Diagram

Models: **16CUXL**
16CUXM
16CUXP

Latching ON or OFF with X10 Unit ON or OFF command.
Momentary On with X10 Unit ON command.
Pulsed On (1 sec) with X10 Unit ON **AND** OFF command.

Channel Number = X10 Unit Code Number

